Mimer III SoftRadio

Connecting radios all over the world

Setting up your

Mimer NetworkRepeater

2861 & 2861/02



Release date Aug 31, 2023

This guide will help with the setup of your Mimer NetworkRepeater or Mimer NetworkRepeater LE.

A NetworkRepeater is delivered as Windows software.

There is a separate description of setups when using both a NetworkRepeater and a RadioServer.

Please also refer to the standard setup instructions for SoftRadio and to the information provided on the web pages.

Please also refer to the web pages:

www.lse.se

www.lse.se/networkrepeater

FAQ: <u>www.lse.se/mimer-softradio/faq/#TNR</u>

All setup guides are found here: <u>www.lse.se/setup</u>

1 Table of Contents

1	TA	ABLE OF CONTENTS
2	GI	ENERAL
	2.1	The product
	2.2	Two sizes
	2.3	INTRODUCTION
	2.4	RECOMMENDED HARDWARE
	2.5	INSTALLATION
	2.6	INSTALLED AS A WINDOWS SERVICE
3	SE	T UP OF THE CONNECTIONS IN THE NETWORKREPEATER
4	SF	PECIAL FUNCTIONS9
	4.1	USING ALIAS NAMES
	4.2	SETTING UP THE LOCAL BROADCAST NET
	4.3	USING A SATELLITE CONNECTION
	4.4	USING THE NETWORK REPEATER WITH ZONES
5	SE	TTING UP MIMER SOFTRADIO TO WORK WITH A NETWORKREPEATER
6	U	SING BOTH A NETWORKREPEATER AND A RADIOSERVER
7	A	DDING THE OPTION "MIMER INTERCOM" TO THE NETWORKREPEATER 12
	7.1	FUNCTIONALITY
	7.2	Setting up the server
	7.3	Setting up the client (at the operator)
	7.	3.1 In a local network, LAN (standard)13
	7.	3.2 In a wide area network, WAN/Internet13
8	PF	ROBLEM SOLVING

2 General

Mimer NetworkRepeater is a component in the Mimer family of products.

It is typically used in systems where you have base station radios spread out at different sites connected via the Internet or a private WAN, and all your dispatchers at one single site.

The NetworkRepeater handles all logon to the remote radios with their respective Network Interfaces. This makes them appear to the system as local radios. Any number of dispatchers can then access each radio without extra network load.

In this way the internet path will not be so heavily loaded as if all users would access all radios one by one, and there is no need for RadioServers.



Example of system with radios at four sites and all operators in one centre. The NetworkRepeater is placed in the same subnet as the operators.

2.1 The product

The Mimer NetworkRepeater is delivered as a Windows software package. Hardware is usually not included in the delivery.

2.2 Two sizes

The Mimer NetworkRepeater comes in two versions supporting a different number of devices.

A device can for example be a radio, phone or intercom connected to the Mimer SoftRadio system.

- Mimer NetworkRepeater
 60 devices (can be expanded)
- Mimer NetworkRepeater LE
 8 devices

The number of operators is not limited. It can be any number up to the SoftRadio systems limit of 240 nodes (radios, operators, servers etc.)

2.3 Introduction

Radio Operators

The radio in a Mimer system is connected to the operator network using Mimer Network Interfaces. If the radio is placed far away, in a different subdomain of the network, the connection to the interface has to be a TCPconnection.

A Network interface can handle just one single TCP connection. So without extra equipment, just one operator can connect to the interface. If there are many operators located at the same place, the Network Repeater can expand this by making this TCP connection to the interface at the radio site, and simulate a locally placed interface that many operators can have access to using UDP connections.



UDP Broadcast TCP UDP Broadcast TCP UN/ The Internet

Network

Repeater

Two or more operators can connect to the network interface over a local LAN.

Over WAN or the Internet only one connection can be made. This will be a TCP connection. The NetworkRepeater makes this connection and then makes many connections to operators over the local LAN using UDP.

Radio unit and

Network Interface

The Network Repeater is typically installed on a separate Server computer in the local network.

After installation, the connections to the radio network interfaces needs to be defined. This is done in a similar way to the settings in the Mimer SoftRadio client.

Repeater ID: 59		Broadcast Source IP: 19	2.168.0.156 Service Co	nnected	Version: 4.0.0.1	
Туре	ID	Name/Status	IP/URL	Conn. type	Remote Port	~
Rem. NetwIntf	152	UHF	mptab.mine.nu	TCP	20952	
Rem. NetwIntf	162	MPT	mptab.mine.nu	TCP	20962	
Rem. NetwIntf	172	VHF	mptab.mine.nu	TCP	20972	
Rem. NetwIntf	192	Hytera MD785	mptab.mine.nu	TCP	20992	
Rem. NetwIntf	138	Connecting	212.214.78.154	TCP	20838	
Rem. NetwIntf	139	Fladan	212.214.78.154	TCP	20839	
Rem. NetwIntf	140	Program	212.214.78.154	TCP	20840	
Loc. Intercom	167	Intercom				
Rem. NetwIntf	109	Connecting	192.168.0. <mark>4</mark> 8	TCP	20909	
Rem. NetwIntf	108	Connecting	192.168.0.14	TCP	20908	-

Example of the Mimer NetworkRepeater running

2.4 Recommended hardware

We recommend running the software on a separate Windows Server or Windows PC. In small systems the server function may be placed on one of the operator PCs.

In systems with for example a Mimer VoiceLog, the server can be shared between the two applications.

The application is very small and does not require a special PC/Server. Any modern unit will work.

2.5 Installation

Install the software package from the supplied USB stick or download.

2.6 Installed as a Windows Service

From version 4.0 and onwards the NetworkRepeater software is installed as a Windows Service on the server. This means that it auto starts with the server itself and always runs in the background. If the server is rebooted, the NetworkRepeater will automatically start up again.

3 Set up of the Connections in the NetworkRepeater

- Open the "NetworkRepeater Console".
- □ Go to "Setup Open Setup Dialogue...".
- Select a unique ID number for the NetworkRepeater. It can be any number 10-240 that is not in use by an operator or other device in the system.

📊 Mi	imer Netwo	ork Repeat	er Console		
File	Setup				
Repe Type	Open Selec	Setup Dia t specific	alogue Network to use fo	r Local Broadcast	: Ci
Rem. N	letwIntf	152	UHF	mptab.mine.nu	1
Rem NetwIntf		162	MDT	motab mine p	4

ile	Vetwork I Help	Repeater Setup						\$2 <u></u>		×
Ne	twork Rep	beater ID: 59	Encry	pt passwords	Allow alias for uni	t names	Interc	om option is in	stalled	
-	Active	Type	nData (Mime	IP/Host name	Connection	Remote port	Alias/Identity	Password	BufDly	
1	Yes	Rem. Netwintf	152	mptb.mine.nu	ТСР	20952		abc123	5	
2	Yes	Rem. Netwintf	162	mptb.mine.nu	TCP	20962		abc123	5	
3	Yes	Rem. Netwintf	172	mptb.mine.nu	TCP	20972		abc123	5	-
4	Yes	Rem. Netwintf	192	mptb.mine.nu	TCP	20992		abc123	5	-
5	Yes	Rem. Netwintf	138	212.214.78.154	TCP	20838		abc123	5	
6	Yes	Rem. NetwIntf	139	212.214.78.154	TCP	20839		abc123	5	
7	Yes	Rem. Netwintf	140	212.214.78.154	TCP	20840		abc123	5	
8	Yes	Loc. Intercom	167			a.	Intercom	_		
9	Yes	Rem. NetwIntf	109	192.168.0.48	TCP	20909		abc123	3	
10	Yes	Rem. Netwintf	108	192.168.0.14	TCP	20908		abc123	3	
11							4			
12										
13										
14										
15	ĺ									
16										
				🗸 Apply	and dose	X Cancel and	close	🖌 Apply	/ Settings	

Setup window for the Mimer NetworkRepeater

- Add a connection that specifies the first interface using the following settings:
 - Active

Set Active to Yes on the first line.

Type

Normally you set "Rem. NetwIntf". (If you have installed the InterCom option you will also be able to choose "Loc. Intercom").

ID

Enter the ID of the Network Interface. It is a number in the range 10-240 that is defined in the Network Interface.

IP/Host name

Enter the IP address, or URL, to the Network Interface at the device.

Connection

Normally set the Connection type to TCP. The second choice "Ext UDP"

is only used when connecting to a Mimer RadioServer over a satellite link.

Remote Port

Select the Remote TCP port. This is configured in the interface as the "TCP server port". The factory default for the interfaces is port 20997. If you have several interfaces behind a router, on the same IP address, you may want to use port forwarding to route the data to each interface. You will then need to set different port numbers to each interface.

On the other hand, if the interfaces are accessed on different IP addresses they may use the same port number.

Alias/Identity

This selection is valid if you have ticked the box above "Allow alias for unit names". This will change the name presented to the dispatcher. Further described later in this manual.

Password

Specify the password for the connection to the Network Interface. This is defined in the Network Interface.

Buf Dly

Set the buffer delay. For a high quality and very short TCP connection a value of 4 or 5 can be used. This corresponds to a buffering of approximately 130-160ms before playback starts. If you encounter dropouts in the sound due to a low-quality connection you may increase this value to handle higher time jitters in the data transfer. Values up to 48 can be used.

Buffer length setting is further explained on this web page: www.lse.se/mimer-softradio/basic-settings/audio-settings/#A9

- You have now defined the first connection. If the Network Repeater shall serve more devices, just add these in the same way.
- □ Finally press [Apply and Close]

4 Special functions

4.1 Using Alias names

Each radios name is set in the Network Interface that is connected locally to the radios. This is then displayed in SoftRadio so that the dispatcher knows which radio he is working with.

In some systems it is practical to be able to change this name without travelling to the radio base station site. With the Alias function activated, the Network Repeater will rename what is displayed at the dispatcher. (Nothing will be changed in the network interface itself)

Practical in systems where the base radios are connected over 4G/LTE and are moved around for different events. The administrator can then rename the radios for each event from a central position.

The function is activated in "Network Repeater Setup" by ticking the box "Allow alias for unit names".

4.2 Setting up the local broadcast net

If the PC/Server that the NetworkRepeater is run on has several IP networks connected, maybe both physical and also virtual networks like VPN tunnels, you will need to select the one that the broadcast to the dispatchers shall work on.

The setting is accessed from the "Setup" menu.

		1379.5
IP-address	Network card description	
192.168.0.156	Realtek PCIe GBE Family Controller	
198.19.2.21	TAP-Windows Adapter V9	
127.0.0.1	Software Loopback Interface 1	
elect the network of	ard to use for broadcasting over the local subnet	
Select the network o	ard to use for broadcasting over the local subnet	

Select local broadcast network

4.3 Using a satellite connection

When connection to the network interfaces at the radios are done over a satellite link the latency and jitter becomes very high. To help the system to handle this, there are a special version of the Mimer RadioServer that needs to be installed at the radio end.

When setting up the Mimer Network Repeater to connect to a satellite version Radio Server the connection protocol shall be set to "Ext UDP".

You will also need a higher buffer delay than normal. Please test your connection and set the delay to the lowest possible but still with an acceptable connection.

1	Vee	Dom Notwietf	402	motob mino ou	TCD	20042		5	
5	Yes	Rem. Netwintf	138	212.214.78.154	Ext. UDP	20913	secret	20	-
0	103	Ren. Netwint	109	212.214.70.134	TOP	20314	SECIEL	3	-

Buffer length setting is further explained on this web page: www.lse.se/mimer-softradio/basic-settings/audio-settings/#A9

4.4 Using the NetworkRepeater with Zones

In large SoftRadio systems with more than 240 nodes, the system is divided into Zones that each can hold 240 nodes.

Selecting the tick box "Zones" will open up for setting of different Zones. This is further described in the separate Zones setup guide. If no Zones are used untick the box or leave all Zone settings at 0.

5 Setting up Mimer SoftRadio to work with a NetworkRepeater

In the operator PC's "Mimer Connections Setup", you specify the device connection just as usual, but you now have local UDP interfaces in the NetworkRepeater instead of remote TCP connected interfaces. So instead of the IP address, or URL, to the interface, you specify the IP address of the Server that is running the NetworkRepeater.

This also means that if the NetworkRepeater connects to more than one device, you will end up specifying the same IP address for several devices. But the network interfaces ID's will of course be different.

24	No	182		192.108.0.182	LocalODP		3
25	Yes	138	Vässarö	192.168.0.156	LocalUDP		3
	Yes	139	Harbour	192.168.0.156	LocalUDP		3
	Yes	140	Airfield	192.168.0.156	LocalUDP		3
	Yes	167	Intercom	192.168.0.156	LocalUDP		3
29	No	110		192 168 0 110			3

6 Using both a NetworkRepeater and a RadioServer

In some system setups you need to use both a RadioServer and a NetworkRepeater. Typically, when you have both radios and operators spread out at different sites connected by the Internet.



- The NetworkRepeater connects to the radios that are at different sites using TCP over the Internet.
- The local operators connect to the NetworkRepeater using UDP.
- The RadioServer also accesses the radios via the Network Repeater using UDP.
- The external operators then connect to the RadioServer using TCP over the Internet.

Please compare with the drawing earlier in this manual where the operators are at the same site. Then the NetworkRepeater is placed there and no RadioServer is needed.

The use of both servers in the same system is further described in a separate guide "Using both RadioServer and NetworkRepeater" available on the download page <u>www.lse.se/setup</u>.

7 Adding the option "Mimer InterCom" to the NetworkRepeater

There is an option to the NetworkRepeater that allows operators to use an intercom channel between themselves. This is practical if the operators are in different rooms or even at different locations.

7.1 Functionality

The operator gets an extra device panel that looks similar to the radio and phone devices. The panel has a PTT button for transmission on the intercom channel. It has a button for an announcement tone on the intercom channel and it has an open/close loudspeaker button just as all other devices.

All operators with the loudspeaker open on the intercom channel will hear all messages.

The announcement tone will be heard regardless if you have the intercom speaker open or closed. When an announcement tone is sent the name bar will blink in green on all operators until one operator transmits.

7.2 Setting up the server

- Close the NetworkRepeater application.
- Install the Intercom option on the server running the NetworkRepeater.
- Restart the NetworkRepeater application.

Then open the settings dialogue.

- Activate a line for the intercom function.
- Set the type to "Loc. Intercom".
- Give the intercom a unique ID number in the Mimer System (10-240).
- Give the intercom an identity. This will be the name that shows on Mimer SoftRadio's name bar.
- Repeat these steps if you need more than one intercom channel.

0	Tes	Rem. Werwintr	128	212.214.70.134	TCP	20039		secret	2	
7	Yes	Rem. Netwintf	140	212.214.78.154	TCP	20840		secret	5	
8	Yes	Loc. Intercom	167				Intercom			
9	Yes	Rem. Netwintf	109	192.168.0.48	TCP	20909		seret-1	3	
10	Yes	Rem. Netwintf	108	192.168.0.14	TCP	20908		secret-1	3	
11							6			

The setup window with row 8 set as an intercom channel



7.3 Setting up the client (at the operator)

In the program "Mimer Connection Setup", where you set up the radios and other devices that the operator shall connect to, you need to set up also the intercom as a device. Please note that each intercom uses one of the total number of devices that you can connect, standard on Mimer SoftRadio is eight devices and with Mimer SoftRadio XL you can connect 30 devices.

7.3.1 In a local network, LAN (standard)

With the operator and the NetworkRepeater in the same subnet of a LAN.

You specify the IP address of the server that runs the Mimer NetworkRepeater and the ID number that have been set up for the intercom function.

20	NO	159		192.100.0.130	LOCAIODP		3	
27	Yes	140		192.168.0.156	LocalUDP		3	
	Yes	167	Intercom	192.168.0.156	LocalUDP		3	
20	1/	44.0		400 400 0 440	Lassiupp		<u></u>	
				102.100.0.110	20001001		Ŭ.	
30	No	118		192.168.0.118	LocalUDP		3	

Example from Connections Setup using a local LAN

7.3.2 In a wide area network, WAN/Internet

When the operator and the NetworkRepeater are not in the same subnet of a LAN.

The connection from the client is made with TCP and you will need to connect the operator through a Mimer RadioServer to the NetworkRepeater.

Please see the instructions for the RadioServer. If unclear send a question to mimer@softradio.se.

8 Problem solving

On the SoftRadio web pages there is an FAQ page. It has a section for common issues when setting up a system with a NetworkRepeater.

www.lse.se/mimer-softradio/faq/#TNR



Proudly made in Sweden by

LS Elektronik AB

www.lse.se

info@lse.se