Page 1

# Mimer SoftRadio for Trig TY92 Airband radio

## Remote functionality

This cable kit will together with the Mimer Network Interface give remote control of the radio's audio and PTT functions.

It will also, through a Virtual Control Head, give the possibility to change channel and adjust the squelch.

## Radio programming

No special programming is needed in the radio.

#### Cable Kit

The red wire to the interface, shall be connected to **+12VDC** for older interfaces. Interfaces over serial 10 000 can be used on 24VDC.

The black wire is common GND to interface and radio.

The network interface consumes max 0,3A.

The blue wire to the radio, shall be connected to +24VDC.

Network Interface connected to the radio and Control Head.

LIIL







#### Version /04

The 3328/04 cable kit has an extra connector where a standard Trig Control Head can be connected in parallel with SoftRadio.

# Audio Volume Settings when using Trig Control Head

Changing the volume settings on the control head also effect the audio path to the Mimer Network Interface.

Set the volume control knob on the control head to zero, (full anti clockwise) and leave it there.

## **Virtual Control Head functions**

